

Material examination and classification using computer vision

construction robotics

international M.Sc.programme



# Material examination and classification using computer vision

- **Task Description**
- **Objectives & Workflow**
- **Dataset**
- **Particle Size Detection Approaches**

Material examination and classification using computer vision | Construction & Robotics

- Result
- **Implementation Plan**
- **Schedule**

# **Task Description**

### Material examination and classification using computer vision









#### **Background**

- Piles of materials are often delivered to the construction site.
- →Unmanned intelligent construction management
- Integration of robots with RGB-D cameras
- The biggest challenge of these studies is related to materials with similar shapes and textures.[1]→(Granular materials)

#### Goals:


Particle size and distribution prediction

[1] Maryam Soleymani, Construction Material Classification on Imbalanced Datasets Using Vision Transformer Architecture (Vit)

# **Objectives & Workflow**

### Material examination and classification using computer vision

#### **Automated Particle Size Detection Workflow**




Slide by Baiyi

## **Research methods**


## Material examination and classification using computer vision

- Regression-Based Method
- Use a CNN model to extract features from each image.
- Map features to numerical values.
- Training set results correlate features with specific numerical outcomes.



Material examination and classification using computer vision | Construction & Robotics

- Classification-Based Method
- Train a CNN model to extract features from each image.
- Map features to corresponding labels.



Slide by Baiyi

### **Dataset**

### Material examination and classification using computer vision

### **Dataset Preparation**

- Image Source: Collected from Aachen Bauhaus and OBI, including 20 types of construction granular materials.
- **Product Diversity:** Ranges from 1-3mm gravel to 40-60mm marble.
- Sampling and Labeling: Products are representing the construction industry. (The most common construction particle size range is 0.075-80mm[1]). These products have <u>small grain size variances</u> and have been labeled. Easier for labeling, feature extraction, and machine learning.



- Image Specifications:
- Manual photography
- Consistent lighting conditions
- Fixed camera distance: 30mm
- Image resolution: 3024x4032 pixels



[1] K.V. Anusree, G.M. Latha, Characterization of sand particle morphology: state of the art, Bull. Eng. Geol. Environ. 82 (2023) 269.

# Particle size detection approachs


### Material examination and classification using computer vision

- Regression-Based Method
- Use a CNN model to extract features from each image.
- Map features to numerical values.
- Training set results correlate features with specific numerical outcomes. **CNN** model

regression




input




# **Segmentation and Feature extaction**

## Material examination and classification using computer vision

- Segment materials into individual particles using a segmentation model (e.g., SAM).
- Extract features from each particle using OpenCV.
- Estimate particle size distribution.





Input picture → Segment materials into individual particles → Extract features

# Particle size detection approachs

### Material examination and classification using computer vision

- Classification-Based Method
- Train a CNN model to extract features from each image.
- Map features to corresponding labels.

**CNN** model classification

Category	Characteristics	Product Names
Fine Pebbles and Gravel	Small size, rounded to semi-rounded,	Marmorkiesel_Weiss_7-15mm,
	smooth to medium roughness	Marmorkiesel_Weiss_15-25mm,
		Marmorkiesel_Gruen_15-25mm,
		Quarzkies_Rund_Hell_8-16mm, Kies_2-
		8mm, Kies_8-16mm, Kies_1-3mm
Medium Pebbles and Gravel	Medium size, rounded to semi- rounded, smooth to medium roughness	Marmorkiesel_Weiss_25-40mm,
		Marmorkiesel_Weiss_40-60mm,
		Marmorkiesel_Schwarz_40-60mm,
		Quarzkies_Rund_Hell_16-32mm, Kies_16-
		32mm, Marmorsplitt_7-12mm, Splitt_2-5mm
Large Pebbles and Broken Stones	Large size, irregular shape, rough texture	Bruchsteine_Veronarot_30-60mm,
		Schieferplaettchen_22-40mm,
		Marmorsplitt_Veronarot_9-12mm,
		Marmorsplitt_Donaublau_8-12mm,
		Basaltsplitt_8-12mm, Granitsplitt_8-12mm,
		Marmorkiesel_Weiss_15-25mm



Categories: x

#### Classification Criteria:

Combines particle size, shape, and smoothness.

#### Three categories:

- 1 Small particles (0-15mm)
- 2 Medium-sized particles (aesthetic, suitable for decoration and outdoor paving)
- 3 Large and rough particles (suitable for construction, providing higher friction)

Challenges: Overfitting during training, further optimization needed

# Implementation plan

## Material examination and classification using computer vision



### Step 2

Ensure the camera is positioned at the optimal 30mm distance.



### Step 4

Utilize a pre-trained CNN model to process the images.



### Step 6

Display and analyze the results for construction site management.



Deploy the robot to navigate to the material pile.



### Step 3

Capture RGB images under controlled lighting conditions.




### Step 5

Predict the particle size using the model.



## **Schedule**



### Sources

https://paperswithcode.com/task/material-recognition/codeless https://www.cs.columbia.edu/CAVE/software/curet/ https://www.csc.kth.se/cvap/databases/kth-tips/index.html https://www.fmdsa.org/research-network/ http://opensurfaces.cs.cornell.edu/ https://en.wikipedia.org/wiki/Convolutional\_neural\_network https://image-net.org/challenges/LSVRC/ https://towardsdatascience.com/r-cnn-fast-r-cnn-faster-r-cnn-yolo-object-detection-algorithms-36d53571365e https://arxiv.org/abs/1312.6229 https://viso.ai/deep-learning/vgg-very-deep-convolutional-networks/ http://yann.lecun.com/exdb/publis/pdf/farabet-pami-13.pdf https://arxiv.org/abs/2304.07193



Thanks for listening. Any Question?

construction robotics

international M.Sc.programme